

View Online at <https://aerobasegroup.com/nsn/6635-01-043-9197>

Mounting Type:

Bench

Current Type:

Ac

Drive Type:

Belt

Angular Unbalance Location Method:

Graduated dial

Maximum Working Weight Capacity:

200.0 pounds

Minimum Working Weight Capacity:

9.6 ounces

Swing Maximum Diameter:

24.800 inches

Maximum Distance Between Bearing Shoulders:

29.000 inches

Work Support Type:

Roller

Vibration Sensitivity Rating:

0.000001 millimeters

Voltage In Volts:

380.0

Phase:

Three

Frequency In Hertz:

50.0

Reference Data And Literature:

Tech order= 32a1-13-1; operation and maintenance manual--dynamic balancing machine model rs2b; e3a

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

T137-e