Flow Rate Indicating Meter - Page 1 of 2



View Online at https://aerobasegroup.com/nsn/6680-01-303-0232

| Overall Length: | |
|--|--|
| 2.625 inches | |
| Media For Which Designed: | |
| Air or gas | |
| Inlet Connection Type: | |
| Hose nipple | |
| Integral Relief Valve: | |
| Not included | |
| Accessory Components And Quantity: | |
| Top mtd. Valve w/ screwdriver adjustment | |
| Meter Type: | |
| Float | |
| Design Type: | |
| Case | |
| Unit Type: | |
| Mounted | |
| Scale Quantity: | |
| 1 | |
| Construction: | |
| Inclosed w/sight window | |
| Outlet Connection Type: | |
| Hose nipple | |
| Scale Marking: | |
| Scfh air | |
| Scale Type: | |
| Direct capacity reading | |
| Float Quantity: | |
| 1 | |
| Tube Material: | |
| Plastic | |
| Mounting Method: | |
| Surface panel | |
| Carrying Handle: | |
| Not included | |
| Dial Scale Marking Range: | |
| +0.1/+1.0 | |
| Base: | |
| Not included | |
| Float Type: | |
| Free | |
| Float Material: | |
| Steel, stainless or glass or polyamide nylon | |

Flow Rate Indicating Meter - Page 2 of 2



| Integral Heat Source: |
|--|
| Not included |
| Metering Tube Quantity: |
| 1 |
| Dial Scale Reference Pointer: |
| Not included |
| Float Quantity Per Tube: |
| 1 |
| Spinning Float: |
| Not included |
| Integral Pulsation Dampener: |
| Not included |
| Inlet Connection Position For Which Designed: |
| Horizontal |
| Inlet Connection Device Type: |
| Stationary |
| Outlet Connection Position For Which Designed: |
| Horizontal |
| Outlet Connection Device Type: |
| Stationary |
| Alarm Signal: |
| Not included |
| Shelf Life: |
| N/a |
| Unit Of Measure: |
| |
| Demilitarization: |
| No |
| Fiig: |
| T134-t |
| |